



### INSTALLATION INSTRUCTIONS

1. Using the spacer as a template, mark and drill (5) 3/16 dia. holes.
2. Install the (5) rawl plugs and fasten the (2) bottom screws of the spacer.
3. Remove backing paper from gasket and place gasket on spacer with bottom of gasket aligned with bottom of spacer.
4. Install the cover assembly with the (3) remaining hinge screws.

### CLEANING INSTRUCTIONS

1. Rinse cover with water to remove abrasive dust and dirt.
2. Wash with soap or mild detergent using a soft cloth. (DO NOT SCRUB.)
3. Rinse once more, then dry with a soft cloth or chamois.
4. To remove grease or wet paint, rub gently with a cloth wetted thoroughly with naphtha, then wash and rinse. (DO NOT USE RAZOR BLADES.)

## INSTALLATION OF STI-6520, STI-6521 and STI-6522 BOPPER STOPPER®

All specifications and information shown were current as of publication and are subject to change without notice.

6520/21/22IS FEB2020