



INSTALLATION INSTRUCTIONS

1. Center the wire guard over existing exit lamp.
2. Mark and drill (4) mounting holes (see pictorial for size).

Lag Bolts - If lag shields and lag bolts are used, make sure rawl plug is flush with surface. Position guard, insert lag bolt and tighten. Length of bolt should be selected to assure full thread engagement in rawl plug.

For installations that require tamperproof fasteners, order KIT-81 stainless steel screws and part no. 19038 bit.

Model	Width	Height	Depth
STI-9640	13.75 in. (349 mm)	10.5 in. (267 mm)	2.75 in. (70 mm)

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details. Electronic warranty form at www.sti-usa.com/wc14.

INSTALLATION OF STI EXIT SIGN DAMAGE STOPPER® STI-9640

All specifications and information shown were current as of publication and are subject to change without notice.

9640 FEB2017

