



MOUNTING BACK PLATE

1. Slide back plate screw into slot (figure A).
2. Install back plate over back plate screw.
3. Thread on back plate hex nut.

MOUNTING FEET INSTALLATION

1. Use recessed hole as guide to drill 0.25in [6mm] through hole in (4) corner locations (figure B).
2. Insert mounting foot into the recessed pocket on back box (figure B).
3. Insert mounting foot hex nut into pocket on mounting foot (figure C).
4. Insert mounting foot bolt and tighten.

MOUNTING TO WALL OR SURFACE

1. Mark mounting hole locations.
2. Choose appropriate mounting hardware for surface and load.

DIMENSIONS MODEL	INTERNAL			EXTERNAL		
	A	B	C	D	E	F
ES-121005-0	10.8 in. (274mm)	9.4 in. (240mm)	4.9 in. (124mm)	14.0 in. (355mm)	9.9 in. (250mm)	6.4 in. (163mm)
ES-161608-0	14.3 in. (366mm)	15.2 in. (388mm)	7.1 in. (181mm)	17.4 in. (442mm)	15.8 in. (400mm)	8.7 in. (220mm)
ES-231609-0	22.2 in. (565mm)	15.2 in. (387mm)	8.3 in. (211mm)	25.4 in. (645mm)	15.8 in. (401mm)	9.8 in. (250mm)
ES-312312-0	30.0 in. (762mm)	22.9 in. (582mm)	10.8 in. (276mm)	33.2 in. (843mm)	23.6 in. (600mm)	12.6 in. (320mm)

One year limited warranty (from date of purchase). See website for details.
Electronic warranty form at www.sti-usa.com/wc14.

INSTALLATION OF ES ENVIROARMOUR® FIBERGLASS ENCLOSURES

All specifications and information shown were current as of publication and are subject to change without notice.