



1. Ensure the cover is firmly pressed onto either the frame or the spacer (Model dependent).
2. Drill a 2.2mm hole through both at approximately 45 degrees on either of the bottom corners, with the cover remaining firmly pressed on to the frame or spacer.
3. Ensure the holes are free from debris.
4. Pass the break seal through both holes before sealing it.

### INSTALLATION OF STI/BS ON STI STOPPER II

All specifications and information shown were current as of publication and are subject to change without notice.