

# Stopper II Sounder Conversion Kit

Upgrading the Stopper II to a Stopper II with Integral Sounder CKS005

1. Take the Stopper cover and remove the non sounder component by unscrewing the anti tamper screw. This is located at the top of the Stopper cover. You will need to use an allen key, which is supplied with the CKS005 to remove the screw.
2. Swap out with the sounder unit (CKS005).
3. Re-insert the tamper screw and tighten to secure the sounder unit.
4. House the retaining cable tabs into the frame, and slide switch into “ON” position.
5. Replace the cover onto the frame and test by removing the cover. The horn should sound when removed and silence when cover is replaced.

