STI Safety Technology International

Protective Cabinet

STI-7534, STI-7535 and STI-7535AED

Features

· Clear, protective polycarbonate cover with siren/strobe alarm.
· Design allows visibility at any angle.
· Complete with mounting hardware and gasket.
· Includes wire shelf, backing plate and siren/strobe alarm — AED models
· External mounting tabs or internal drill dimples.
· Cover includes a coated steel internal mounting plate with a baked on white enamel finish.
· Siren/strobe alarm lens is red. Also available with amber, green, blue or white lens.
· Siren offers 32 user selectable tones.
· Alarm can be set for a piercing 100 dB or 85 dB.
· Independent strobe and siren timing of 15 seconds, 30 seconds, 60 seconds or continuous.
· Powered by a 9 VDC battery or external 12-30 volts.
· Low battery indicator.

We protect the things that protect you.®

Table of Contents

Warnings

All units are recommended for indoor use. Unit must be tested periodically to verify the life of battery. STI recommends you change the 9 Volt battery twice a year. When purchasing a siren/strobe alarm, you will need to periodically test the connections to make sure audibles function at a sound level to alert staff. Installer may need to purchase a simple audio-meter, typically available at your local electronics store, to measure the sound in areas where the alarm is expected to be heard during normal noise environment. Results from this test may prove it beneficial to purchase additional siren/strobe alarm units.

All specifications and information shown are current as of publication and subject to change without notice.

Cleaning

1. Rinse cover with water to remove abrasive dust and dirt.
2. Wash with soap or mild detergent using a soft cloth. (DO NOT SCRUB.)
3. Rinse once more, then dry with a soft cloth or chamois.
4. To remove grease or wet paint, rub gently with a cloth wetted thoroughly with naphtha, then wash and rinse. (DO NOT USE RAZOR BLADES.)

Dimensions

597mm
(23.5 in.)

310mm
(12.2 in.)

419mm
(16.5 in.)

360mm
(14.2 in.)

1/4"
DIAMETER

FRONT VIEW

164mm
(6.44 in.)

BOTTOM VIEW

Specifications

Operating Voltage	Internal power 9 VDC battery (not included)
	Remote power 12-30 VDC
Operating Temperature	32°F -120°
Power Consumption	Stand by: 50µA
	Siren low volume: 85mA
	Siren high volume: 90mA
	Strobe: 25mA
Siren Volume	Low: 85 dB
	High: 100 dB
Alarm Timing	Independent control for siren and strobe:
	30s, 60s, continuous
Low Battery Warning	LED flash once every 30 seconds
Form C Dry Contacts Rated For	0-30VAC/DC, 1 Amp
	Contacts reset after longest alarm setting
Key Switch	Alarm on: normally closed
Alarm Switch	Stand by: normally open contact required
Polycarbonate Flammability Rating	UL94V-2

Installation of Cabinet

Note:

Installation of cabinet should be before installation of alarm because the mounting bracket butts up to cabinet.

1. Insert the (4) M06298 mounting tabs fully into backbox mounting tab slots. Use rubber mallet if necessary.

R04875 MOUNTING PLATE PROVIDED

#10-12 x 1 in. ANCHOR (4) PROVIDED

#8-32 x 3/8 in. SCREW (4) PROVIDED

OPTIONAL SHELF MOUNTING POSITION

MOUNTING TAB SLOTS

STI-7530 KEYLOCK STI-7531 AND STI-7531AED THUMBLOCK

M06298 MOUNTING TABS (4) PROVIDED

19013 SCREW #10 x 1 1/2 in. (4) PROVIDED

W07530 ADJUSTABLE SHELF INCLUDED WITH STI-7531AED ONLY

CABINET ASSEMBLY

G6297530 GASKET PROVIDED

2. After selecting a suitable location, place cabinet in closed position, against the wall. Mark and drill (4) 1/4 in. diameter holes. Insert the (4) 19033 anchors. Mount cabinet by driving in the four #10 x 1 1/2 in. screws.

3. For STI-7531AED select one of the two shelf mounting locations, install shelf. Close and lock cabinet.

Installation of Alarm
STEP 1 - Mounting Options
To key mount plate or into wall without electrical box

DRILL 3/16 DIA HOLES

KIT-SA505 KEY SWITCH MOUNTING BRACKET

H18074 SWITCH LOCK

#801 KEY

3 9/32 in.

BASE PLATE

#6 x 1 1/4 in. SCREW (2) PROVIDED

ANCHOR #8-10 (2) PROVIDED

ENCLOSURE

ROUTE THE TWO KEY SWITCH WIRES THROUGH THE HOLE AS SHOWN

ROUTE THE TWO REED SWITCH WIRES FROM CABINET THROUGH THE HOLE AS SHOWN

WIRE ACCESS HOLE

STEP 2 - Electronic Setup
## Select alarm tone and timing sequence

Note: Select-Alert must be on a flat surface and lens must be installed or the tamper switch will trigger the alarm.

Step 3 - Alarm Tones - S1

	12345	
* 1	00000	BUZZ
2	10000	SLOW ON/OFF
3	01000	SLOW SIREN
4	11000	3 BEEP/PAUSE/REPEAT
5	00100	UFO FAST
6	10100	FAST SIREN
7	01100	#5 FAST
8	11100	#2 MEDIUM
9	00010	#5 MEDIUM
10	10010	SWOOP MEDIUM
11	01010	#3 MEDIUM
12	11010	BUZZ TONE
13	00110	STEADY FAST
14	10110	SWOOP SLOW
15	01110	CONTINUOUS
16	11110	FAST REPEAT

	12345	
17	00001	STANDARD ALARM
18	10001	#3 FAST
19	01001	#5 SLOW
20	11001	FAST BEEP
21	00101	SOUND A
22	10101	SOUND B
23	01101	SOUND C
24	11101	SOUND D
25	00011	SOUND D LOUD
26	10011	SOUND E
27	01011	SOUND F
28	11011	SOUND G
29	00111	SOUND H
30	10111	#4 LOW
31	01111	SOUND K
32	11111	CONTINUOUS FAST

WIRES TO SIREN

Note: Sound may be disabled by clipping wires to the siren. THIS WILL VOID ALL WARRANTIES. Remove two screws on circuit board; leave enough length of wire to possibly reattach in the future. Then insulate wires to prevent shorting to electronic components.

Step 4 - Alarm Timing and Volume - S2


ALARM TIMING	SIREN		STROBE		VOLUME
	1	2	3	4	5
* 15 seconds	1	1	1	1	High 1
30 seconds	1	0	1	0	
60 seconds	0	1	0	1	Low 0
Continuous	0	0	0	0	

1 = ON   **0 = OFF**

*Factory default settings

Step 5 - Electronics Assembly

Wiring: After mounting circuit board assembly, connect wires. Refer to terminal strip connections (step 6).

Lens installation: Slide lip of lens behind circuit board mounting plate. Rotate lens into position. Secure with tamperproof screw and special. ⚠ Unit will not operate properly if lens cover is not installed.

ELECTRONICS

M05050- LENS COLOURS
A - AMBER
B - BLUE
G - GREEN
R - RED
W - WHITE

INSTALLED
BASE PLATE

TAMPER-PROOF
SCREW

ROUTE WIRES
THRU HOLE

TAMPER-PROOF
TOOL (1) PROVIDED

WIRE ACCESS HOLE

#8-32 x 3/8 in. SCREW
(4) PROVIDED

Step 6 - Terminal Strip Connections

Note "DC IN" are the only polarity sensitive terminals.
When external power is used, battery will act as a backup. "Dry Contacts: NC, COM, NO" are used for remote alarm monitoring.

REMOTE POWER IN
12-24 VDC, 125mA
(OPTIONAL)

DC IN
KEY SWITCH
ALARM SWITCH
NC COM NO

OFF ON

MAIN POWER
CONTROL TO
KEY SWITCH

NORMALLY OPEN

COM   NORMALLY CLOSED

ACTIVE

FORM "C"
DRY CONTACTS

STAND
BY

REED
SWITCH FROM CABINET

Assembly Parts List
SIREN/STROBE ALARM

QTY.	PART #	DESCRIPTION
1	05000	Electronics assembly (includes base plate & electronics assembly)
1	05050-R	Red lens (unless otherwise specified)
1	09723	Key switch mounting bracket
2	18075	#801 key
1	18074	Switch lock
1	18151	N.C. reed switch and magnet (installed in cabinet)
4	19002	Screw #8-32 x 3/8 in.
2	19039	Screw #6 x 1 1/4 in.
2	19018	Anchor #8-10
1	19011	#8-32 x 1/2 in. tamper screw
1	19016	Tamper wrench
1	BAT-9VDC	9 volt battery

CABINET

QTY.	PART #	DESCRIPTION
1	07530	Hinged polycarbonate enclosure
4	06298	Mounting tabs
4	19013	#10 x 1 1/2 in. screw
4	19033	Plastic anchor
1	07530WR	Wire shelf (included with AED models only)
1	04875	Mounting plate
4	19002	#8-32 x 3/8 in. screw
1	6297530	Gasket
1	07503	Thumb lock - STI-7535 models
1	18050	Key lock ⎫ STI-7534 models
2	18054	CH751 ⎭

Step 7 - Operation

· Turn key switch onto arm.
· Cycle key switch to reset alarm
· Alarm will sound when cabinet is opened (alarm switch is electronically closed), alarm cover is removed or unit is removed from the wall.
· To service, turn key switch off.

Warranty

· Three year guarantee against breakage of polycarbonate housing (one year on electro mechanical and electronic components).

· Electronic warranty form at www.sti-usa.com/wc14.

Accessories and Replacement Parts

STI-SA5000-R   Replacement Siren/Strobe Alarm - Red
KIT-H18054   Replacement key for cabinet lock on STI-7534
KIT-H18075   Replacement key for Siren/Strobe Alarm
KIT-W07530   Wire shelf (included with AED models)